

I. Part Names, Fig. 1




Fig. 1

- ❶ Charging Indicator
- ❷ Power Indicator
- ❸ Charging Slot
- ❹ DC Power Jack: center electrode connected to the positive voltage.

II. Operating Instructions, Fig 2




Fig. 2

1. Insert the transmitters into the charging station in correct direction.
2. Connect the DC power input jack to the MP-8.
3. Power Indicator: Indicator is lit when power plug is plugged in and the power supply is normal.
4. Charging Indicator: red light indicates charging; green light indicates full charge. It doesn't work if there is no transmitter inserted.
5. Cautions:
  - (A) Be sure to use the included MIPRO charger to avoid inadequate voltage or current. Ensure input supply voltage must not exceed a specified value to avoid damages to the charger, rechargeable batteries and transmitters. MIPRO power supply has switching power output 12V/1A.

## Single Slot Transmitter Charging Station


---

- (B) Power off the charger before charging.
  - (C) Do not use other brands' charger, to avoid possible danger.
6. Note: Refer to actual product in the event of product description discrepancy.



## MP-8 Single Slot Transmitter Charging Station

### User Guide



**MIPRO Electronics Co., Ltd**

Headquarters: No. 814, Beigang Rd., Chiyai City 600079, Taiwan  
Tel : +886.5.238.0809 Fax : +886.5.238.0803  
www.mipro.com.tw mipro@mipro.com.tw



All rights reserved, Do not copy or forward without prior approvals of MIPRO. Specifications and design subject to change without notice. YM 022/03



2CE602A